



2 in 1 Hand Warmer with LED Torch

Instruction Manual



Thank you for purchasing our product. Please read all the instructions before attempting to operate this product and save the instruction manual for future reference.

PRODUCT DIAGRAM



Specifications


Charge in	5V/1A
Charging time	Approximately 3 hours
Warmer operation time	Approximately 4-5 hours (depend on ambient temperature)
Surface heating temperature	Approximate 42°C
Size	6(L) x 6(W) x 2.2(H) cm

Remarks: Product performance (operating time & surface temperature) varies in different environments.

Operation Instruction

Charging the unit

- Charge the unit with the USB cable from computer or USB socket AC; the charging LED will show in red color during charging.
- When the red charging LED Indicator turns to green color, it means the charging is finished.
- Charging the unit for 3 hours before first use is recommended.
- For a better battery performance, it is recommended to recharge the appliance after the battery is exhausted.
- Always place the appliance in a safe and flat surface to charge.
- The unit will not operate when charging is in process.
- Do not charge the unit under a cover or inside the carrying pouch, it may cause overheating.
- Do not charge the unit over the recommended period, it will shorten life-span of the battery or may cause explosion.
- The high performance Li-ion rechargeable battery can be recharged for approximately 300 times.



Using the unit as a warmer

1. Long press the Power Switch, the LED light of switch will show in green, it means the unit is warming up.
2. After a while, the LED will turn off, it means the surface temperature reaches 42°C. When the temperature is below 42°C, the LED will turn green again.
3. Long press the Power Switch to turn off the unit.
4. Stop using the warmer if erythema, itch, blain is detected.

Using the unit as a LED torch light

1. Short press the Power Switch, the LED torch light will turn on.
2. Short press the Power Switch again, the LED torch light will turn off.

Notes:

1. The warmer and LED torch light can be used in the same time.
2. If the LED light of Power Switch turns red, the unit is in low power.

IMPORTANT SAFEGUARDS

READ ALL INSTRUCTIONS BEFORE USING YOUR APPLIANCE

1. This appliance is for warming and LED light purposes only; do not use for any purpose other than described in this manual.
2. Do not dispose of the appliance in fire, the Li-ion battery may cause explosion.
3. Do not immerse the USB cord and the unit into water.
4. Do not store the appliance in hot environment. High temperature may shorten the life span of the appliance or damage the battery.
5. Do not disassemble the appliance by yourself.
6. Do not put the appliance inside or next to a microwave oven, oven or other high temperature equipment, this may cause fire or explosion.
7. Do not use the appliance near explosive or inflammable materials; it may cause fire or explosion.
8. Do not use the appliance in bathroom or wet and damp area; this may damage the appliance.
9. Always keep the appliance dry.
10. Do not use the appliance with unoriginal parts or accessories.
11. Stop using or charging the appliance if strange odor, overheating is detected. Take the appliance to the repairing centre for examination.
12. If battery leakage is detected, stop using the appliance. Avoid contacting the liquid with eyes and skin.
13. If the appliance is damaged, it must be repaired by the manufacturer, its service agent or a similarly qualified person to avoid hazard.
14. Do not use chemicals, cleaning solvents or strong detergents to clean the appliance. Use a soft dry cloth to clean the surface of the unit.
15. If the unit is not in use for a long period, fully charge it and store it in a cool, dry place. Keep it away from children.
16. This appliance is not intended for use by children or other persons without assistance or supervision if their physical, sensory or mental capabilities prevent them from using it safely. Children should be supervised to ensure that they do not play with the appliance.

